



INSTALLATION INSTRUCTIONS

PART#: SMX-SSB25

FITS: Chevrolet/GMC

•2011-2018 Silverado/Sierra 2500HD/3500HD

Thank you for choosing SuspensionMaxx for your vehicle. This kit is designed to add suspension travel and increase ground clearance. **By installing this kit you are accepting the vehicle will have a higher lifted stance. This increase the Vehicle ride height and roll center. These modifications will change the handling and high speed maneuverability of a vehicle. Caution should be used when driving and operating a lifted vehicle. Not heeding the following warning may result in the crash or rollover of the vehicle, resulting in bodily injury or death.** Specially designed tools and experience are required to complete the installation properly. These parts should only be installed by a ASE qualified mechanic otherwise an unsafe vehicle and/or injury may result. Consult manufactures service manual for proper torque specifications and procedures. Safety is important. Use safe working habits. Instructions are for both sides. Repeat the steps to both sides.

DISCLAIMER

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Although this material has been prepared with the intent to provide reliable information, no warranty (express or implied) is made as to its accuracy or completeness. Neither is any liability assumed for loss or damage resulting from reliance on this material. SPECIFICALLY, NO WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY IS MADE OR TO BE IMPLIED WITH RESPECT TO THIS MATERIAL. In no event will Suspension Maxx Incorporated or its parent or affiliates be liable for any damages, direct or indirect, consequential or compensatory, arising out of the use of this material.

THE INFORMATION, PRODUCTS, MATERIALS AND SERVICES CONTAINED IN THIS SITE, INCLUDING WITHOUT LIMITATION, GRAPHICS, TEXT AND LINKS ARE PROVIDED ON AN "AS IS" BASIS WITH NO WARRANTY OF MERCHANTABILITY, FITNESS FOR A SPECIFIC USE OR REPRESENTATION OF ACCURACY.

REVISIONS TO TERMS AND CONDITIONS

Please refer to these Terms and Conditions regularly. Suspensionmaxx.com reserves the right, at any time, to modify, amend, alter or update these Terms and Conditions without prior notice by updating this posting. Your continued use of the Site following posting of changes to these Terms and Conditions signifies that you agree to be bound by such modifications, amendments, alterations or updates.

LIMITATION OF LIABILITY

IN NO EVENT SHALL Suspensionmaxx.com BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, CONSEQUENTIAL OR ANY OTHER DAMAGES WHATSOEVER, WHETHER IN ACTION OR UNDER CONTRACT, TORT OR OTHERWISE. Under no circumstance, including, but not limited to, negligence, shall Suspensionmaxx.com be liable for any damages that result from the use of, or inability to use, the information, materials or products contained in or purchased from this site. Further, Suspensionmaxx.com shall have no liability or responsibility for any delay in the delivery, installation or use of the products, as well as the service life of the products, performance, applicability for the use intended, proper installation, or the accuracy of information provided. Suspensionmaxx.com shall have no liability for any computer virus or other computer disruptions or damages to any software or hardware of any user of this site.

MAXX LIMITED STRUCTURAL WARRANTY

SuspensionMAXX stands behind its Leveling kits with a limited structural warranty, covering defects in material and workmanship. This warranty does not cover normal wear and tear or any other loss, liability or damage resulting from improper installation, disassembly handling or use of the product. Manufacturer shall not be liable for any incidental, consequential or other damages resulting from the disassembly, installation or use this product. The loss of use of the product, loss of time, inconvenience and consequential damages are not covered. Consumer is responsible for all labor charges, removal and reinstallation of the product.

INSTRUCTIONS

SuspensionMAXX kits are designed to be easily installed and completely reversible to the factory supplied settings. These instructions are supplied for ease of installation, correct procedures and safety. Automotive experience recommended.



PATENT PENDING

Again, Thank you for your purchase! Enjoy your SuspensionMAXX leveling system!

Questions? E-mail us at tech@suspensionmaxx.com or call 1.888.629.9226

SECTION 1: Installation

1. Jack and support front of vehicle under frame with load rated jack stands. (Allow the suspension to relax fully by supporting the frame)
2. Remove front wind-deflector/skid-plate to gain access to crossmember.

3. On the front driver side locate lower control arm bolt and nut on the crossmember

WARNING: DO NOT FULLY REMOVE BOLT IN THE PROCEEDING STEPS AS IT MAY RESULT IN INJURY!

Using a wrench for the bolt and a ratchet bit remove nut.

See **FIG 1-1**



4. Carefully back bolt out a 1/4-1/2 inch using a rubber mallet. **DO NOT FULLY BACK OUT BOLT!**

5. On the head side of the bolt slide bracket shim into place. Open end should face down.

See **FIG 1-2**

6. Slide stabilizer bracket upward over the bolt. Notch on bracket should slide in place over the bracket shim.



7. Continue holding bracket in place & insert included bolt through both the hole in the bracket as well as the back side of the crossmember.



8. From the front side of the crossmember, insert sleeve over the bolt and into the crossmember. See **FIG 1-5 & FIG 1-6**

NOTICE: Be careful not to drop the sleeve inside of the crossmember during assembly.

9. Install washer nut onto the provided bolt. Torque to **90 lbs/ft.** See **FIG 1-6 & FIG 1-7**

10. Install factory nut back onto the lower control arm bolt and torque to **120 lbs/ft.**


11. Using the provided short bolt and nut install steering dampener to the bracket as showing in **FIG 1-8.** Tighten nut and bolt to **45 lbs/ft.**

12. Install opposite end of the steering dampener to drag link. Torque to **35 lbs/ft** See **FIG 1-9**

13. Reinstall front wind-deflector/skid-plate.

14. **Before operating vehicle check for proper clearance & operation of steering systems after installation.**


15. **Check torque specs of fasteners at 500 miles.**



Again, Thank you for your purchase! Enjoy your SuspensionMAXX leveling system!

Questions? E-mail us at tech@suspensionmaxx.com or call 1.888.629.9226

SHOCK INSTALLATION DIAGRAM



Again, Thank you for your purchase! Enjoy your SuspensionMAXX leveling system!
Questions? E-mail us at tech@suspensionmaxx.com or call 1.888.629.9226